

Installation Instructions

Van Security Window Screens

Important!
Read Before Installing Screens!

WARNING

Window screens can reduce the driver's ability to clearly see roadways, vehicles, people and other objects through the rear and side windows of the vehicle - which can cause an accident. Driver must make all adjustments necessary for maximum visibility. This includes, but not limited to: adjusting mirror and seating positions.

Installation Tools

- Protective eyewear
- Drill with 5/16" hex driver socket
- Wire cutters
- Grinder

Fasteners

1/4" - 14-3/4" self drilling screws & 1/4" flat washers

Installation Instructions

1. Place screen over window frame and mark areas that need fastening loops cut off or bent for best fit.
2. Some interior window trim may need to be removed.
3. Allow for full window latch clearance before fastening.
4. Grind any sharp edges smooth. Fasten screens after aligning properly.

CAUTION

Always wear protective eye wear when installing screens to protect from debris

