

## **SnowDogg® Snowplow Headlight Adapter**

### **INSTALLATION INSTRUCTIONS**

**16071180**

**GM FORWARD LAMP HARNESS ADAPTER**

**GM 1500 2014+**

#### **INSTRUCTIONS**

- 1.** Connect the leg of the 16071180 adapter labelled "This end to relay module" to the SnowDogg relay harness.
- 2.** Disconnect the vehicle headlight harness from the front light housing.
- 3.** Connect the 16071180 adapter to the light housing.
- 4.** Connect the 16071180 adapter to the vehicle headlight harness.
- 5.** Check all light functionality before operating the plow.

Note: This adapter will not work on 2007-2013 GM vehicles. While the connectors are the same, the wiring is not compatible.